

Concept Question 9-14: Why can upsampling and interpolation obviate the need for a continuous-time lowpass filter with many circuit elements?

A selective analog lowpass filter, such as a Butterworth filter, requires many circuit elements, connected using Sallen-Key circuits. Upsampling and interpolation implements a selective filter in discrete time, which merely requires more computation and storage.